

## CCV


# CISCO PACKET TRACER

### **SAURABH PUNDIR**


181510028, 28

CCV


## 1. Bus Topology



## 2. Star Topology




## 3. Ring Topology



# Step 1: Set up the network topology

- a. Add many generic PCs, Switches (as per required to make the topology).
- b. Connect each PC to switches using ethernet cables as shown in above figures.
- c. Connect Switches to Switches wherever required.
- d. Double Click on any Laptop/Desktop, in order to configure the network parameters.
- e. Enter the IP address for each PC:
- f. Go to Desktop Tab
- g. Enter the IP Configurations Setting.

h. Enter the IP address, Subnet Mask and Default-Gateway.




### Step 2: Verify connectivity

- a. Click any PC and select the Desktop tab.
- b. Select Command Prompt.
- c. Type ipconfig at the prompt to view the IP configuration.
- d. Type ping 192.168.X.X to ping the from any device to 192.168.X.X.

```
PC0
                                                                                                                                                                                                                    Config Desktop Programming
   Physical
                                                                                          Attributes
     Command Prompt
                                                                                                                                                                                                                                 Х
    Packet Tracer PC Command Line 1.0 C:\>ping 192.168.0.6
     Pinging 192.168.0.6 with 32 bytes of data:
    Reply from 192.168.0.6: bytes=32 time=11ms TTL=128 Reply from 192.168.0.6: bytes=32 time<1ms TTL=128 Reply from 192.168.0.6: bytes=32 time=3ms TTL=128 Reply from 192.168.0.6: bytes=32 time=11ms TTL=128
    Ping statistics for 192.168.0.6:
Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
Minimum = 0ms, Maximum = 1lms, Average = 6ms
    C:\>ping 192.168.0.3
     Pinging 192.168.0.3 with 32 bytes of data:
    Reply from 192.168.0.3: bytes=32 time=24ms TTL=128 Reply from 192.168.0.3: bytes=32 time=3ms TTL=128 Reply from 192.168.0.3: bytes=32 time=11ms TTL=128 Reply from 192.168.0.3: bytes=32 time=10ms TTL=128
    Ping statistics for 192.168.0.3:
Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
Minimum = 3ms, Maximum = 24ms, Average = 12ms
    C:\>
Тор
```

The pings to all devices should be successful.

## Topology:




## AIM:


- Configure 3 routers.
- Configure DHCP.
- Configure DNS.


## **Steps:**


Set up the network topology

- a. Setup the Topology as Shown.
- b. Configure routers.











c. Configure DHCP and DNS Server as:





### d. Most Important:

Go to each router and run following commands:


#### enable


#### configure terminal


### interface FastEthernet0/0

#### ip helper-address 192.168.2.2


e. Set IP assignment to DHCP for every host. IPs will be automatically assigned as:







## Topology:



#### **AIM**

- Send Mails.
- Access FTP.
- Access HTTP(Browser).


### **Steps:**


#### Set up the network topology

- a. Setup same topology as Activity 3.
- b. Configure Mail Server.
- c. Setup Domain name.
- d. Add 2 users with username and password.
- e. Setup Desktop/Mail on 2 hosts and login with the accounts.
- f. Send mail from one to another.
- g. Configure FTP Server.
- h. Add account as earlier.
- i. Go to any host/Desktop/Command Prompt.


#### ftp 192.168.2.2

enter username and password use command dir





### **Topology:**



#### AIM:

• Connect 3 PCs to a wireless router •

Change the DHCP setting to a specific network range

• Configure the clients to obtain their address via DHCP.

#### **Background / Scenario**

A home user wants to use a wireless router to connect 3 PCs.

All 3 PCs should obtain their address automatically from the wireless router.

#### Step 1: Set up the network topology

i. Add three generic PCs.

ii. Connect each PC to an Ethernet port to the wireless router using straight-through cables.

#### Step 2: Observe the default DHCP settings

a. After the amber lights have turned green, click PCO. Click the Desktop tab. Select IP Configuration. Select DHCP to receive an IP address from DHCP Enabled Router.

Record the IP address of the default gateway: 192.168.0.1

- b. Close the IP Configuration window.
- c. Open a Web Browser.
- d. Enter the IP address of the default gateway recorded earlier into the URL field. When prompted, enter the username **admin** and password **admin**.
- e. Scroll through the Basic Setup page to view default settings, including the default IP address of the wireless router. Notice that DHCP is enabled, the starting address of the DHCP range and the range of addresses available to clients.

#### Step 3: Change the default IP address of the wireless router.

- a. Within the Router IP Settings section, change the IP address to: **192.168.0.1**.
- b. Scroll to the bottom of the page and click Save Settings.
- c. If it is done correctly, the web page will display an error message. Close the web browser.
- d. Click IP Configuration to renew the assigned IP address. Click Static. Click DHCP to receive new IP address information from the wireless router.
- e. Open the web browser, enter the IP address **192.168.0.1** in the URL field. When prompted, enter the username admin and password admin.

#### Step 4: Change the default DHCP range of addresses.

a. Notice the DHCP Server Start IP Address is updated to the same network as the Router IP.

- b. Starting IP Address 192.168.0.100.
- c. Maximum Number of Users to 50.
- d. Scroll to the bottom of the page and click Save Settings. Click Continue.
- e. Scroll back up to the DHCP Settings to ensure the change is made.
- f. Close the web browser.
- g. Select Command Prompt. Enter ipconfig. Record the IP address for **PCO**: 192.168.0.103

#### Step 5: Enable DHCP on the other PCs.

- a. Click PC1.
- b. Select Desktop tab.
- c. Select IP Configuration.
- d. Click DHCP. Record the IP address for PC1: 192.168.0.101
- e. Close the configuration window.
- f. Enable DHCP on PC2 following the steps for PC1.


#### Step 6: Verify connectivity

- j. Click PC2 and select the Desktop tab.
- k. Select Command Prompt.
- I. Type ipconfig at the prompt to view the IP configuration.
- m. Type ping 192.168.0.1 to ping the wireless router. Type ping 192.168.0.103 to ping PC0. Type ping 192.168.0.101 to ping PC1.

The pings to all devices should be successful.

# **Activity 5**

#### Topology:



#### Aim:

- Connect various IOT devices.
- Trigger IOT Events.

### Steps: Topology

- a. Connect devices as shown.
- b. Assign static IP addresses to all devices.
- c. Turn on registration server from IOT service section.
- d. Double click on IOT devices and select remote server.
- e. Enter server IP address.
- f. Enter username and password as:

Username=admin

Password=cisco

- g. Got to the web browser on the server, enter IP address of server.
- h. Login with same username password.
- i. You can now configure devices and also make events.

